Stand Mode for Datalogic Scanners

Enable Stand Mode (default behaviour)







Disable Stand Mode



Enter/Exit Programming Mode
Wait for green light on top of scanner to flash



